



NOTE TO PRINTER:
USE DIELINE FROM FRONT OF PACKAGE.
THIS DIELINE IS ONLY APPROXIMATE.

1 Attach four super suction cups at corners of glass first.

2 Tighten the cup by pressing against the glass and turning about 1/3 of a turn clockwise. See figure A.

3 Attach 5 regular suction cups as shown, with 2 on top. See figure B.

4 To remove super suction cups turn 1/3 turn counter-clockwise and pull on tab.



Questions or Comments?
Contact Consumer Information, 1-800-760-2060
Made in China
Monahan Products LLC
371 Liberty Street, Suite 502
Rockland, MA 02370
Owner of registered trademark Uppa Baby

